





**IF MOISTURE IN TRANSFORMER
INSULATION DRIVES BUBBLE FORMATION,
REMOVE IT CONTINUOUSLY —
NOT PERIODICALLY.**

Prevent Bubble Formation with Continuous Moisture Control

- ✔ Shifts moisture out of insulation
- ✔ Lifts the temperature margin for bubbles
- ✔ Reduces failure risk before overload



 **drytrans**

 vishal@drytrans.com
www.drytrans.com